

# Metal Roof Electrical XL Adapter Installation Instructions

Metal Roof Electrical XL Adapter · ZEA-A XL MR


1-1/4" O.D., 1" I.D. NPSM

#### Parts included:

- A. Electrical XL Adapter with (2) EPDM O-Rings
- B. Electrical XL Base Plate

### **Tools needed:**

- Drill/Driver
- 1-3/4" hole saw



#### **Installation Steps**

# Install Adapter

Select a spot on the roof to allow the entire diameter of the Adapter to sit flush against the roof to create a waterproof seal.

Check for obstacles, measure a minimum

Create a center mark for your hole. Drill a


of 4-1/2" from joists, bracings or seams.

through hole using a 1-3/4" hole saw.

1-3/4" hole


# **9** Secure Base Plate

**Thread** the Adapter into the Base Plate from above or below depending upon clearance. Ensure raised feature on the Base Plate is facing up for best seal.




**NOTE:** Once the O-ring and Base Plate are in firm contact with the metal roof material, spin 1/4 turn to tighten.


## DO NOT OVERTIGHTEN




With an O-ring pressed in the channel on the underside against the metal roof insert the long end of the Adapter into the hole.



**3** Complete the Installation Attach components such as a Conduit Body or Junction Box as necessary.



**Note:** when using a Combiner Box, insert the second O-Ring between the Adapter and body of the box to create a water tight seal. Secure with 1-1/4" lock nut.



One or more patents apply to this product including without limitation: US Pat. 8,448,405; 8,479,455; 8,661,765; 8,689,517; 8,707,654; 8,707,655; 8,752,338; 8,833,032; 8,833,033; 8,869,490; 9,068,339; 9,106,023; 9,473,064; D415,847; D617,174; D636,656; D639,143; and/or D639,144.